

Quick Start Guide for the IDAutomation SC7USB 2D Barcode Scanner

Introduction

This scanner will automatically scan a barcode at a distance of 3 to 8 inches from the symbol when the trigger is pulled. The scanner is programmed by scanning barcodes from the manual when viewed on the screen at 200% or more magnification from the PDF. Successful scanning shall be obtained by tilting the scanner with respect to the barcode to avoid direct reflections that impair reading performance.

Installation

1. Connect the USB cable between scanner and PC.
2. To enable USB keyboard emulation, scan the appropriate barcode below:



USB HID (PC)



USB HID (MAC)

3. If the scanner does not operate properly, remove the scanner from the USB port and plug it into another port after scanning one of the USB HID barcodes above.
4. If the scanner still does not operate properly, remove the cable from the PC and pull the cable out of the scanner. Reinsert the cable in the scanner.