



IDAutomation SC7USB 2D: Auto-Sense Mode (Continuous Mode)

Set Scanner to Auto-Sense Mode



Auto-sense Mode

Set Scanner to Manual Mode (Default)



***Manual/Serial Trigger**