

IDAutomation SC5USB-D: Return Scanner to Factory Default

1. Scan the Program Barcode



2. WARNING: Default value initialization

If you wish to return to all the factory default settings, scan the Default value initialization bar code.

