

Code 39

Start/Stop Characters

Start/Stop characters identify the leading and trailing ends of the barcode. You may either transmit, or not transmit Start/Stop characters. Default = Don't Transmit.

Check Character

No Check Character indicates that the scanner reads and transmits barcode data with or without a check character. Default = No Check Character.



<Default All Code 39 Settings>



***On**



Off



Transmit



***Don't Transmit**



***No Check Character**



Validate and Transmit



Validate, but Don't Transmit