


## IDAutomation SC5USB: Transmit Symbology Name


### 1. Scan the Program Barcode




### 2. Scan the Symbology Name Barcode



### 3. To enable Symbology Name, scan 0, 1 (to disable 0,0)



### 4. Scan Finish Barcode



### 5. Scan the Exit Barcode

