

Keyboard Country

Scan the appropriate country code below to program the keyboard for your country. As a general rule, the following characters are supported, but need special care for countries other than the United States:

@ | \$ # { } [] = / ' \ < > ~



* United States



Belgium



Brazil



Canada (French)



Czech Republic



Denmark



Finland (Sweden)



France



Germany/Austria



Greece



Hungary



Israel (Hebrew)

Keyboard Country (continued)



Italy



Netherlands (Dutch)



Poland

Portugal



Romania



SCS

Slovakia



Spain

Sweden



Switzerland (German)



Latin America



Norway



Russia



Keyboard Country (continued)



Turkey F



Turkey Q



U.K.