

IDAutomation SC7-USB Scanner: Process for Setting Alphanumeric OCR (Changing Fixed-Digit Amount):

1. Clear previous OCR changes made:



<Default All OCR Settings>

2. Select either OCR-A or OCR-B as both types cannot be selected at the same time:



OCR-A On



OCR-B On

3. Scan the Enter code to prepare the scanner for input:

OCR Template Codes



Enter OCR Template

4. Although the SC7-USB has many options, this guide covers alphanumeric OCR only. Scan the barcode below the same amount of times as there are characters to be scanned (scan it 8 times for 8 characters, 10 times for 10 characters, etc.):



a

5. Scan the Save code to tell the scanner input is finished:

Exit Selections



Save OCR Template